

Installation Instructions for V-Rod Rear Turn Relocation Bracket By Lazer Star

Note: Fine scratches around the turn signal mounting holes are part of the manufacturing process. Some steel wool with little effort will remove these scratches. There is also a "line" at the very tips of the bracket that is a mark from the tooling used to bend the bracket. This will also come off with steel wool but will require more effort. This mark should be above the fender line and not visible when installed. When using steel wool be sure to only rub in the same direction as the brushed finish. Also, the stock factory turn signals will not fit with this bracket. Some sort of aftermarket signal utilizing a single mounting point must be used.

1. Begin by opening your seat and disconnection the battery.
2. remove the ignition box and unplug
3. Remove the rear "outer" fender by removing the 4 bolts located under the seat area.
4. Disconnect the taillight, license plate and turn signal wires.
5. Remove the black plastic piece by removing the 4 bolts located on both sides and forward of the piece; there are 2 on each side. Once the bolts are removed, the unit will slide straight rearward and come off.
6. Loosen the 4 bolts (2 on each side of the fender) that hold the "inner" fender to the strut. **DO NOT REMOVE THEM!**
7. Locate the rear turn signal wires and cut the plugs off. Run the wires down each side of the fender and insert through one of the mounting holes used to hold on the black plastic piece. The wires should now be run to the inside of the fender to connect to the turns.
8. Remove the supplied nuts from the new bracket and insert the 2 threaded studs into the 2 holes located at the back of the fender.
9. At the very front of the bracket you will find 2 tabs. Insert them between the inner fender and the strut. **Do one side at a time.** While inserting push on the side of the bracket at the turn signal mounting hole, hold it flat onto the black bracket on the bike. Adjust the bracket as necessary until the mounting hole is not obstructed. Tighten the bolts on the fender strut that holds the fender to the strut. Repeat for the other side.
10. Reinstall the fender to be sure all lines up. If not loosen necessary bolts and adjust.
11. Install turn signals. (Note: Stock turn signals will no longer fit)
12. Wire license plate light to original wires (LSM0201)
13. Install license plate (LSM0201 – bolts not provided)

For technical assistance please call 1-800-624-6234 or 714-630-9490